

INSTALLATION INFORMATION FOR OUR "P" SERIES HEATER PACKAGES USED WITH RHEEM SE 24, 30 and 36 PACKAGE AIR COND. UNITS.

These are complete one-piece Heaters in the KW, phase and voltage that you require. A combination baffle and support piece is included in the package.

The lower KW Heaters require removal of 3 of the 2" wide blanks covering the Heater insertion area in front of the blower while the higher KW units require all 4 to be removed.

The baffle-support is to be installed first. Insert it with the slots to your left. When in place these slots will straddle the rails in front of the blower and MUST be on the blower side of the existing screws in the rails to prevent it sliding to the left. The Heater is inserted next on top of the support bracket. Our Heater terminal plate mounting holes will match those that were in the blank plates over the opening. Screw fast top and bottom.

The controls wiring plug will match the unit receptacle. The heavier lead wires for field connection should be put through the hole provided into the unit controls space. You are now ready for field connection of high voltage to these lead wires.

BE SURE to use a thermostat that will interlock the fan on the heating cycle - one designed for Electric Heat application.

